



Edelbrock Elite Series Top Mounting Bolt-On Breather Part #4202 & #4212 INSTALLATION INSTRUCTIONS

1. Using baffle plate bosses on inside of Elite Series valve covers as pilot holes, drill 11/32" holes completely through valve cover.
Also enlarge baffle plate mounting holes.
NOTE: These breathers will not fit Elite Series valve covers #4244, #4246, #4247, or #4248.
2. Clean all chips and burrs from cover and plate.
3. Install grommet, baffle plate, and breather with bolts, nuts and washers supplied.

©2010 Edelbrock Corp.
Part #4202 & #4212

Edelbrock Corporation • 2700 California St. • Torrance, CA 90503
Tech Line: 800-416-8628 Office/Sales line: 310-781-2222

Rev. 5/10 - AJ/mc
Brochure #63-4202



Edelbrock Elite Series Top Mounting Bolt-On Breather Part #4202 & #4212 INSTALLATION INSTRUCTIONS

1. Using baffle plate bosses on inside of Elite Series valve covers as pilot holes, drill 11/32" holes completely through valve cover.
Also enlarge baffle plate mounting holes.
NOTE: These breathers will not fit Elite Series valve covers #4244, #4246, #4247, or #4248.
2. Clean all chips and burrs from cover and plate.
3. Install grommet, baffle plate, and breather with bolts, nuts and washers supplied.

©2010 Edelbrock Corp.
Part #4202 & #4212

Edelbrock Corporation • 2700 California St. • Torrance, CA 90503
Tech Line: 800-416-8628 Office/Sales line: 310-781-2222

Rev. 5/10 - AJ/mc
Brochure #63-4202



Edelbrock Elite Series Top Mounting Bolt-On Breather Part #4202 & #4212 INSTALLATION INSTRUCTIONS

1. Using baffle plate bosses on inside of Elite Series valve covers as pilot holes, drill 11/32" holes completely through valve cover.
Also enlarge baffle plate mounting holes.
NOTE: These breathers will not fit Elite Series valve covers #4244, #4246, #4247, or #4248.
2. Clean all chips and burrs from cover and plate.
3. Install grommet, baffle plate, and breather with bolts, nuts and washers supplied.

©2010 Edelbrock Corp.
Part #4202 & #4212

Edelbrock Corporation • 2700 California St. • Torrance, CA 90503
Tech Line: 800-416-8628 Office/Sales line: 310-781-2222

Rev. 5/10 - AJ/mc
Brochure #63-4202



Edelbrock Elite Series Top Mounting Bolt-On Breather Part #4202 & #4212 INSTALLATION INSTRUCTIONS

1. Using baffle plate bosses on inside of Elite Series valve covers as pilot holes, drill 11/32" holes completely through valve cover.
Also enlarge baffle plate mounting holes.
NOTE: These breathers will not fit Elite Series valve covers #4244, #4246, #4247, or #4248.
2. Clean all chips and burrs from cover and plate.
3. Install grommet, baffle plate, and breather with bolts, nuts and washers supplied.

©2010 Edelbrock Corp.
Part #4202 & #4212

Edelbrock Corporation • 2700 California St. • Torrance, CA 90503
Tech Line: 800-416-8628 Office/Sales line: 310-781-2222

Rev. 5/10 - AJ/mc
Brochure #63-4202